

## **INSTRUCTION MANUAL**



### Vacuum Blender GT-VB800



### **IMPORTANT SAFEGUARDS** (INTRODUCTION)

When using electrical appliances, basic safety precautions should always be followed including the followings:

#### Read all instructions.

- Read these instructions carefully and retain for future reference.
- Remove all packaging and any labels.
- •Take care the blades are very sharp.
- Do not use the vacuum blender more than 3 minutes.

### Safety

• The blades are very sharp, handle with care. Always hold the plastic parts rather than the cutting edge when handling and cleaning.



•Keep hands and utensils away from the blade while blending to reduce the risk of severe injury to persons or damage to the vacuum blender.

## • This appliance will be damaged and may cause injury if the interlock mechanism is subjected to excessive force.

• Before removing the blending jar: switch off first, wait until the blades have completely stopped.

•Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or is dropped or damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair or electrical or mechanical adjustment.

- Never let the power unit, cord or plug get wet.
- Don't let excess cord hang over the edge of a table or worktop or touch hot surfaces.
- Never leave the appliance on unattended.
- Misuse of your vacuum blender can result in injury.
- Never use an unauthorized attachment.

• This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.



• Children should be supervised to ensure that they do not play with the appliance.

•Do not use outdoor, household use only. Supplier will not accept any liability if the appliance is subject to improper use, or failure to comply with these instructions.

•To protect against risk of electrical shock do not put power unit in water or other liquid. Close supervision is necessary when any appliance is used by or near children.

- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Avoid contacting moving parts.

• The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock or injury, or discs on base without first putting bowl properly in place.

- Do not attempt to defeat the interlock mechanism.
- Blade is sharp. Handle carefully.
- •Be certain machine is installed properly before operating appliance.
- •Do not modify the plug in any way.
- •Please do not move the unit during operation.
- •Please do not use the unit at a place that is unstable.

•Please do not put ingredients of a temperature higher than 40°C into the jars. Doing so may cause injury.



•Never perform no-load running. Please do not use the unit with ingredients less than 250ml or exceed Max line.

#### Before plugging in

• Make sure your electricity supply is the same as the rating label one that shown on the underside of the appliances.





### **SAVE THESE INSTRUCTIONS:**

### PARTS DESCRIPTION





### **BLENDING JAR SET**

### VACUUM STORAGE JAR SET







## TO ASSEMBLE YOUR VACUUM BLENDER

### Assemble Blending Jar:

(1) Assemble lid Install Vacuum valve & Blending jar lid pad to Blending jar lid first.



Then install Blending jar seal to Blending jar lid.



Then install Lid filter by rotate clockwise



Press Blending jar lid down to Blending jar by aligning lid tip with jar spout







(2)Assemble blade set

Rotate Blade set anti-clockwise and install it to Blending jar



#### Assemble Vacuum Storage Jar:

Install Vacuum valve & Storage jar seal to Vacuum storage jar



Then install Lid filter by rotate clockwise



Press Storage jar lid down to Vacuum storage jar



### **GOREK TECHNOLOGIES**

101, J.B. Shopping Center-1, Matawadi, L H Road, Surat, Gujarat Contact: +91-9016891389 | +91-9327460898



## **TO USE YOUR VACUUM BLENDER**

Connect plug to power supply and all indicator lights flash for once, then press Power button, the indicator light around Power button goes on, you can start to use now.



#### For vacuum & blending:

Install vacuum storage jar in place:



The vacuum blender has a separate vacuum function, programmed to vacuum the Blending jar or Vacuum storage jar. Press VACUUM button and wait 45 seconds until the indicator light goes out.





#### 1. AUTO function

One click function is an auto feature the Vacuum Blender has.

First press Power button, then just one click the AUTO button, vacuum and blending will be automatically operated with a program of 45 seconds' vacuum & 1 minute's blending, there you are ready to enjoy your smoothie.

**NOTE:** When AUTO program is running, adjust Speed knob manually will be useless; Auto function can be stopped by clicking AUTO button again.

#### 2. Manual function

When you want to blend or grind at your preferred timescale, you can operate the Vacuum Blender in a manual way.

1) Press VACUUM button and wait 45 seconds until the indicator light goes out.

2) Rotate the Speed knob anticlockwise and release soon to proceed with PULSE motion.

3) Dial the Speed knob clockwise to adjust speed.

**NOTE:** When machine is running at a selected speed, press AUTO button will be useless.

The machine will stop working automatically after 2 minutes 30 seconds to ensure user's safety, please re-select speed to use continuously. But in any condition, do not run it over 3 minutes continuously, and please cool it for 30 minutes.

## **DISASSEMBLE YOUR VACUUM BLENDER**

Always release vacuum completely first before opening Upper cover, blending jar lid and Storage jar lid, otherwise you can't open them.







#### Disassemble vacuum storage jar:

(1) If vacuum function has been used, release vacuum to open Upper cover.



(2) Take Vacuum storage jar out to store in refrigerator or take away. When you want to open lid, if vacuum function has been used, release vacuum first.



#### **Disassemble Blending jar:**

(1) If vacuum function has been used, release vacuum to open Upper cover.



(2) Rotate Blending jar anti-clockwise to take it out





(3) If vacuum function has been used, release vacuum to open Blending jar lid



(4) Empty the Blending jar then you can disassemble the blade set.



## **USEFUL TIPS**

**Tips**: It's easier to open Blending jar lid or Vacuum storage jar lid if you use one hand to release the Vacuum seal, and the other hand to open lid, even vacuum function has not been used.



### Important

• If preparing food for babies or young children, always check that the ingredients are thoroughly blended before feeding.

• Do not run the vacuum blender continuously for longer than 3 minutes, leave to cool for 30 minutes between each operation.

• Do not operate the vacuum blender if the Blending jar is empty.



- Always allow hot food to cool before processing.
- Do not place any part of the vacuum blender into a microwave.

### Hints

• If the blender is overload, remove some of the mixture and continue processing in several batches, otherwise you may strain the motor.

• Remember that blending hard foods such as coffee beans, spices, chocolate or ice will wear the blades faster.

• Beware of over processing some ingredients. Stop and check the consistency frequently.

## **Care and Cleaning**

Caution! Danger of injury! The blades are very sharp! Do not touch the blades while cleaning to avoid injury! For safety reason, the blades are not suited for removing them. Caution! Danger of electrical shock! Before cleaning and removing parts, switch off the electric appliance and always remove the plug from the mains. Never immerse the appliance into water. The connector parts must not get wet. Contact of electrical parts with moisture can cause electric shock or short circuit and damage.

- Do not use sharp detergents or metallic, abrasive objects to clean the unit as the surface of the unit or accessories might get damaged.
- If necessary, just wipe the main body with a dry or damp cloth.
- Store the unit in a dry safe place, not reachable by children.

### Service and customer care

- If the cord is damaged it must, for safety reasons, be replaced by an authorized repairer. If you need help with:
- using your appliance or
- servicing or repairs Contact the shop where you bought your appliance.